



54781 08-14 NISSAN TITAN

NISSAN TITAN UPPER CLASS SERIES MESH GRILLE

Tools Required:

Small Slotted Screwdriver 3/8" Socket or Nut Driver

Part List: |

- 1 Upper Class Grille Center
- 2 Upper Class Grille Sides (Right & Left)
- 7 6-32 Nylon Lock Nuts
- 7 ½ x ½ L Brackets

Read and understand instructions before attempting installation

Step 1

Remove the factory grille from the truck. Use a small slotted screwdriver to un-clip the plastic clips. There are four along the top and three along the bottom. Now remove the grille. Remove the plastic clips from support beams and place them in the grille shell.

If you purchased the lower grill see step 3 now.



<u>Step 2</u>

Center the grilles into the openings. Use an 8mm wrench to tighten the L brackets using the nylon nuts provided. Make sure the brackets hold to the grille mesh (1). DO NOT OVERTIGHTEN. Be sure to put the plastic clips onto grille shell. Re-install grill assembly back onto the vehicle using lower guides to align grille and clips

Step 3

Center the lower grille into opening. Reaching behind the bumper, secure the top of the grille with the

provided L- Brackets and nylon lock nuts. Secure the lower portion of the grille using the provided J-hooks and nylon lock nuts. Return to step 2.

Thank you for purchasing a T-Rex Billet Grille.

T-REX GRILLES BILLET GRILLES