



<u>672932X</u> 07-14 тоуота <u>FJ CRUISER</u>

2007-14 TOYOTA FJ CRUISER

X-METAL SERIES MESH BUMPER

Tools Required:

10mm Socket 5/16" Socket

Part List:

- 1 X-Metal Bumper
- 4 6-32 Nylon Lock Nuts
- 4 #10 Flat Washers
- 4 2" Flange Brackets

Read and understand instructions before attempting installation

<u>Step 1.</u>

Unbolt the two 10 mm bolts on top of the grille. Unfasten the three plastic clips securing the grille to the core support; remove the grille.

<u>Step 2.</u>

Center the bumper grille in place. Use the 2" flange brackets, washers and nylon lock nuts to secure the bumper grille.

<u>Step 3.</u>

Re-install the factory grille onto the vehicle. Thank you for purchasing a T-Rex Billet Grille. 10/5/06

