

66032
68032

14-15 CHEVROLET
CAMARO RS



66032
68032

14-15 CHEVROLET
CAMARO RS

CHEVROLET CAMARO RS

Custom Series Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flat/Phillips Screwdrivers

PARTS LIST

- (1) Grille
- (2) 2" Black PVC Tubing 5/32x9/32
- (2) 6/32 Nylon Lock Nuts
- (2) 1/2 x 1/2 L Bracket
- (2) # 10 Flat Washer



Step 1 Radiator Cover Removal & Grille Installation

Open the hood on the vehicle. Now remove the four 10mm bolts from the top of the radiator cover plate (Fig 1). Now remove six plastic pop clips that hold the radiator cover and the bumper cover together (Fig 2). Now remove the radiator cover plate (Fig 3) this will give you access to the rear of the factory grill. Slide the four pieces of black pvc tubing onto the threaded studs that are welded to the back of the mesh grille (Fig 4). Insert the mesh grille onto the factory grill opening (Fig 5). Reach down behind the mesh grille through the radiator cover opening and locate the threaded studs, place the L Brackets on the threaded studs making sure they latch onto the factory plastic bars in the factory grill, place wa washer and the nylon lock nut onto the threaded studs and tighten. Reinstall the radiator cover. Installation complete. Thank you for purchasing a T-REX Grille.



Fig 1



Fig 2



Fig 3



Fig 4



Fig 5



Fig 6