

20938 20938B 12-15 TOYOTA TACOMA



20938 20938B 12-15 TOYOTA TACOMA

TOYOTA TACOMA

Upper Class Billet Grille

Install time: 35 Mins.

TOOLS REQUIRED:

3/16 Drillbit
Screwdriver
Dyegrinder

PARTS LIST:

(1) Billet Grille
(7) #8 3/4 Screws
(7) #8 Flatnuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove 2 Bolts and 1 Clip along the top of the Factory Grille. (Fig.1)
- Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
- With a Dyegrinder, cut along the Factory Grille to remove Grille. (Fig. 2) (Do not remove the Black Tab along the bottom of the Factory Grille)
- Place Billet Grille onto the Factory Grille Shell. (Fig. 3)
- Securely have in place the Billet Grille. (make sure it fits properly) (Fig. 4)
- With a 3/16 Drillbit, Drill through the opening tabs on the Billet Grille. (Fig. 5)
- Insert the #8 Screws through the Holes you Drilled. (Fig. 6)
- Thread with provided Flatnuts. (Fig. 7)
- Place Grille Back onto the Truck. (Fig. 8)

Installation Complete

