

20939
20939B
12-15 TOYOTA
TACOMA



20939
20939B
12-15 TOYOTA
TACOMA

TOYOTA TACOMA

Hood Scoop

Install time: 10 Mins.

TOOLS REQUIRED:

Screwdriver
1/8 Drillbit

PARTS LIST:

(1) Hood Scoop
(2) 1" Screws

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- Place the Hood Scoop onto the Factory Hood Scoop. (Fig.1)
- Drill a 1/8 Hole through the 2 Holes on the Hood Scoop. (Fig. 2)
- Thread with Provided Screws. (Fig. 3)

Installation Complete

