



21276

98-05 CHEVY
S-10 TRUCK

21276

98-05 CHEVY
S-10 TRUCK

S-10 TRUCK and BLAZER
With Factory "Mesh Design" Grille

Tools Required:

Phillips screwdriver
Drill
3/16" Drill Bit

Hardware / Parts Included:

1 Upper Billet Insert (6 bars)
1 Lower Billet Insert (7 bars)
4 8 x 3/4 Screws
4 8 Flat Nuts

Read and understand instructions before attempting installation

Step 1

Your vehicle should have a **single** horizontal chrome bar across the center of the factory grille; the bowtie attaches to this chrome bar. Open the hood and remove the factory grille. Identify the upper and lower billet inserts.

Step 2

Note the four mounting tabs on both billet inserts. Place the lower insert in the factory grille. Center the insert and hold in place. Take a pen or scribe and mark where each bracket hole is. Now drill a 3/16" hole at each mark. Fasten the insert with the screw and flat clips provided.

Step 3

Repeat Step 2 on the lower insert. Re-install the grille assembly back on the vehicle.

Thank you for purchasing a T-Rex Billet Grille. 9/6/06