

# T-REX TRUCK PRODUCTS INC.

**25100**

**03-07 CHEVY**

**SILVERADO**

TOW HOOK

BUMPER INSERT

**25100**

**03-07 CHEVY**

**SILVERADO**

TOW HOOK

BUMPER INSERT

## **2003-2007 SILVERADO** BUMPER TOW HOOK BILLET INSERTS; 2 PC. SET

### **Tools Required:**

Phillips Screw Driver  
Drill  
1/8" Drill Bit

### **Hardware / Parts Included:**

2 - Billet Grille Insert (10 bars)  
6 - #8 x 3/4" Phillip Screws  
6 - #8 Flat Nuts

### **Read and understand instructions before attempting installation**

#### **Step 1.**

Remove the factory tow hooks. Identify the left and right bumper inserts. Test fit the billets into the openings.

#### **Step 2.**

Hold the billets in place and mark the bracket hole to the openings. Drill a 1/8" hole at each mark. Secure the billets using the screws and nuts provided. Make sure the billets are centered and tighten the fasteners.

#### **Step 3.**

Installation is now complete. *Thank you for purchasing a T-Rex Billet Grille.*

2/19/04 T-Rex Truck Products Inc.