

T-REX Billet Grilles

25103

03-07 CHEVY
SILVERADO
TOP BUMPER

25103

03-07 CHEVY
SILVERADO
TOP BUMPER

CHEVY SILVERADO (ALL) BUMPER TOP PAD BILLET INSERTS - 2 PC

Tools Required:

7/16" Wrench
7/16" Socket & Ratchet


Hardware / Parts Included:

2 Billet Grille Insert (4 bars)
2 'Z' Brackets (10205Z)
4 1/4-20 x 3/4 Bolts
4 1/4-20 Nuts
4 1/4 Flat & Lock Washers

Read and understand instructions before attempting installation

Step 1

Identify the left and right bumper inserts.



Here are the passenger and driver side inserts as they appear in the bumper.

Attach the "Z" brackets here with the fasteners provided.

Step 2

Attach the brackets as pictured in the diagram on the right. The brackets then mount to holes on top of the bumper. Make sure the billets are centered and tighten the fasteners. **Thank you for purchasing a T-Rex Billet Grille. 5/9/07**