



25780

04-14 NISSAN
TITAN/ARMADA
BUMPER BILLET

25780

04-14 NISSAN
TITAN/ARMADA
BUMPER BILLET

NISSAN TITAN / ARMADA
BUMPER BILLET

Tools Required:

Phillip Screw Driver
Drill
1/16" Drill Bit

Hardware / Parts Included:

1 Billet Bumper Insert
4 #8 x 1 Screw (#6 Head)

Read and understand instructions before attempting installation

Step 1

Center the bumper into the opening.

Step 2

Mark the four mounting holes on the billet insert to the opening. Remove the inserts and drill a 1/16" hole at each mark.

Step 3

Fasten the billet using a long reach Phillips screwdriver and the small head #8 screws. Do not over-tighten the screws. *Thank you for purchasing a T-Rex Billet Grille. 12/28/05*