

54320
51320
2011 KIA
OPTIMA



54320
51320
2011 KIA
OPTIMA

2011 KIA OPTIMA

Upper Class Mesh Grille

Install time: 30 Mins.

TOOLS REQUIRED:

Screwdriver
Plastic Prybar
10mm Socket Wrench

PARTS LIST:

(1) Mesh Grille
(8) 3/8 x 3/8 L-Brackets
(8) 6/32 Nylon Lock Nuts

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

Step 1

- Remove 8 Clips on the Plastic Cover. (Fig. 1)
- Lift the Plastic Cover and remove.
- Remove 2 10mm Bolts towards the center of the Grille Shell. (Fig. 2)
- Towards the corners of the Grille shell, there will be hooks, With semi-force push the Grille Shell forward and pull up to unlatch the Grille Shell. (Fig. 3)
- Place the Mesh Grille over the Factory Grille. (Fig. 4)
- Pull the Factory Grille Shell outward so you have space (Need another Person to help) and insert the L-Bracket Through the Threaded Screw on the Mesh Grille, Have the L-Bracket latch onto the outer edge of the Factory Grille, Thread with a 6/32 Nylon Lock Nut. (Fig. 5)
- Repeat for remaining Screws.
- Re-Assemble Hooks, Clips and Plastic Cover.

INSTALLATION COMPLETE

