

# **T-REX**

## **Billet Grilles**

54896

05-10 TOYOTA

**TACOMA**

54896

05-10 TOYOTA

**TACOMA**

### **UPPER CLASS SERIES SIDE VENTS – 2 PC**

#### **Tools Required:**

Slotted Screwdriver  
Drill & 1/8" Drill Bit  
5/16 & 10mm Socket

#### **Hardware / Parts List:**

2 Upper Class Vents (Right & Left)  
4 6-32 Nylon Lock Nuts  
4 #10 Flat Washers

### **Read and understand instructions before attempting installation**



#### **Step 1**

Open the hood and remove the factory grille shell. Remove the four fasteners along the top of the grille; (2) 10mm bolts and (2) plastic fasteners. Unclip the remaining two fasteners in each lower corner.

#### **Step 2**

Test fit the grilles over the right and left opening on the grille. Drill a pair of 1/8" holes aligned with the mounting studs on the back of each grille.

#### **Step 3**

Secure the grilles using the nuts and washers provided. Re-install the grille assembly onto the vehicle.

***Thank you for purchasing your T-Rex billet grille. T-Rex Truck Products Inc. 10/24/06***

