

T-REX

Billet Grilles

55198

08-13 CADILLAC

CTS

55198

08-13 CADILLAC

CTS

Cadillac CTS

BUMPER CAP INSERTS

Tools Required:

Phillips & Slotted Screw Drivers
8mm

Parts List:

2 Fog Light Inserts
4 6-32 Nylon Lock Nuts
4 #6 Flat Washers

Read and understand instructions before attempting installation

Step 1

Place the insert over the bumper cap inserts. While holding the insert in place; reach behind the bumper and bumper cap inserts and place a washer and nylon lock on each stud **[1]**.



Step 2

Center the insert and tighten the nylon lock nuts. Repeat this process on the other side.

Thank you for purchasing your T-Rex billet grille. 02/29/08