

**55320  
52320  
2011 KIA  
OPTIMA**



**55320  
52320  
2011 KIA  
OPTIMA**

## **2011 KIA OPTIMA**

### **Upper Class Bumper Mesh Grille**

**Install time: 30 Mins.**

#### **TOOLS REQUIRED:**

Screwdriver  
Plastic Prybar  
10mm Socket Wrench

#### **PARTS LIST:**

(1) Mesh Bumper Grille  
(4) 6/32 Nylon Lock Nuts  
(4) 10/32 Fender Flatwashers

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.**

#### **Step 1**

- With a Screwdriver remove the License Plate from the Bumper. (Fig. 1)
- Remove 8 Clips on the Plastic Cover. (Fig. 2)
- Lift the Plastic Cover and remove.
- Remove 2 10mm Bolts towards the center of the Grille Shell. (Fig. 3)
- Towards the corners of the Grille shell, there will be hooks, With semi-force push the Grille Shell forward and pull up to unlatch the Grille Shell. (Fig. 4)
- Place the Bumper Mesh Grille over the Factory Bumper Grille. (Fig. 5)
- Pull the Factory Grille Shell outward so you have space (Need another person to help) and insert a Fender Flatwasher on the Threaded Screw that is on the Mesh Grille, Thread with a 6/32 Nylon Lock Nut. (Fig. 6)
- Repeat for remaining Screw.
- With a Cutter, Remove the 2 Tabs along the bottom of the License Plate. (Fig. 7 & 8)
- Grind excess material.
- Re-Assemble Hooks, Clips, Plastic Cover and License Plate.

**INSTALLATION COMPLETE**

