

# **55475**

**05-10 DODGE  
CHARGER (SRT)**



# **55475**

**05-10 DODGE  
CHARGER (SRT)**

## **UPPER CLASS SERIES BUMPER**

### **Tools Required:**

5/16" Wrench  
7mm Wrench

### **Hardware:**

- 1 Bumper Insert, (Upper Class Series)
- 4 #10 Flat Washers
- 4 6-32 Nylon Lock-Nuts
- 4 2" Flange Brackets

## **Read and understand instructions before attempting installation**

### **Step 1**

Use a 7mm wrench to separate the engine splash shield from the bumper along the bottom. This will allow access to the rear of the bumper.

Center the grille over the factory plastic inserts. Install a flange bracket, nut and washer on each stud. Tighten the hardware until the grille is held firmly in place.

Re-install the lower splash shield.