

LASER BILLET GRILLE

MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500

PARTS INCLUDED

(1) Laser Billet Grille - Main

Full Opening - Polished - Part #6202130 OR
Full Opening - Black - Part #6202131

HARDWARE INCLUDED

- (5) Trim Retainer
- (4) 1/2 x 1/2 3/16" (Hole) Spacer
- (8) #8 Screw
- (8) #8 Flat Nut

TOOLS REQUIRED

- Drill
- 1/8" Drill Bit
- Screwdriver set (Phillips)
- Vice Grips / Clamps
- Socket Set
- Ratchet Tool
- 1/2" Plastic Spatula Wedge

GRILLE REMOVAL & GRILLE INSTALLATION GUIDE

START HERE

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.
Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model.

* APPLICATION MODELS VARY. WE RECOMMEND TO VERIFY FITMENT BEFORE BEGINNING INSTALLATION PROCESS. * IMAGES FEATURED IN THE INSTRUCTION DOCUMENTS MAY NOT ALWAYS EXACTLY MATCH YOUR GRILL.

STEP 1 FRONT BUMPER REMOVAL

1) Turn off engine and chalk tires with stop block. Open Hood. Disconnect Battery.

PRO TIP:

Before you begin, use "3M Painters Tape" to apply a protective guard around the work areas. Attend to the fender and bumper valance. This will help protect the paint and finish of your vehicle.

STEP 2

2) Begin by removing the plastic core support cover shroud.

There will a number of Plastic "Push Tabs" that secure the cover.

Remove them all and set aside for reinstallation.

Remove Cover and set aside for later.






PAGE 1

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500





STEP 3

SEE FIGURES 4 & 5

3) Remove the factory hardware that secures the grille assembly to the core support.



STEP 4

SEE FIGURES 6 - 9

4) It is now time to loosen the vehicle wheel well fender trim. Start at the top middle, and working your way towards the very front of the fender trim where it meets the front bumper, use a torq bit to remove screws. With the front half fender trim loose and pulled out of the way, (as seen in Figure #7) you can access the additional hardware that secure the plastic lower bumper valance. Remove these bolts and set aside all hardware for re-installation later.



STEP 5

SEE FIGURES 9 - 14

5) At this point, you need to remove the vehicles plastic lower bumper valance (a long and slim trim panel that is located directly above the front bumper, below the grille, and is usually color matched to the vehicle body color). Slip out the valance away from where it meets the front fender. You will need to unfasten several tabs that latch the whole piece from under and behind bumper and underneath headlights.













LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500







SEE FIGURES 16 - 20

6) With the lower plastic bumper valance removed you can now access several bolts at the bottom below the grille lip and above the vehicle bumper and also located (2) more at the lower corners. Remove all hardware that fixes grilles assembly to vehicle.

7) Using both hands, grab the very bottom corners of each side and firmly pull on both sides. This action will pull loose and release the grille assembly from the grille mounts. The Grille should now be free to pull away from truck.



8) Flip the grille assembly over and place on a flat cushioned surface or foam pad to begin disassembly.




STEP 9

SEE FIGURES 21 & 24

9) It is now time to remove the radiator induction shroud.

Remove all the plastic push tabs that secures the shroud and set asides for later.







LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500





STEP 10

SEE FIGURES 24 - 29

10) With the radiator shroud removed and safely out of the way, It is now time cut into the factory grille plastic pattern design and separate the factory grille shell to re-purpose and utilize with your new T-REX Grille.

From the grilles backside, make a proper cutting path using a paint pen or bright marker to highlight the correct cutting patch along the outer edge of the plastic grille pattern.



STEP 11

SEE FIGURE 27

11) To gain familiarity it is recommended to examine the grille face and back side so that you understand where you will be cutting and where and how the new T-REX Grille will insert and mount to the factory grille shell.



STEP 12

SEE FIGURES 28 & 29

12) Using Figures #28 & 29 as reference as proper cut locations around edge and corners, make one final confirmation that your cut line is well clear of the factory chrome shell. You DO NOT want to cut into or damage the chrome shell.







LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131





STEP 13

13) From the grilles backside, use a 90 degree cutoff wheel, zip saw, sawzall or something similar, carefully cut along your marked line.

STEP 14

SEE FIGURES 31, 33, & 34

14) Carefully navigate cutting your corner edges





SEE FIGURES 32-36

SEE FIGURES 30 - 36

15) Carefully continue your cut path along outer edge without damaging factory chrome grille shell.



STEP 16

SEE FIGURES 32-36

16) At this point, check over your work and make certain your cut reflects the images presented here.



GRILLE SHELL DISASSEMBLY COMPLETE



GRILLE ASSEMBLY - START

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

STEP 18








STEP 17

17) Separate the shell from the inner grille piece.

SEE FIGURES 37 - 42

18) For those that do want to feature the GMC Badge, you will need to first remove it from the factory grille and set aside for later use.











STEP 19

SEE FIGURES 43 - 44

19) Using a 90 degree sanding disc, sand paper, file, or something of the sort, clean up and sand down the plastic debris left over from the cut out grille piece.

GRILLE ASSEMBLY CONTINUED

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500







STEP 20

SEE FIGURES 45 - 48

20) Carefully align the t-rex grille so that it sits evenly aligned with the shell and then clamp into place with vice grips or something similar.





SEE FIGURES 48 - 49

21) Once satisfied with the alignment and fitment and with the grille insert clamped in place, mark with a paint pen.

SEE FIGURES 50 -52

22) Flip over to inspect grille fitment of billet face alignment alongside grille shell and for proper sitting depth with shell. If adjustments are needed release clamps, and reset fitment till satisfied.







LOOK OVER YOUR WORK

STEP 23

SEE FIGURES 50 & 52

23) At this point, you should examine and carefully look over your work. Inspect for proper alignment depth and fitment.

GRILLE SHELL ASSEMBLY CONTINUED

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131







STEP 24

SEE FIGURES 53 - 57

24) Once satisfied with the alignment and fitment and with the grille insert clamped in place, drill a 1/8" hole for each of the pre-fixed grille mounting tabs.






STEP 25

25) Insert provided #8 Screws into each hole drilled.

STEP 26

26) Slide on flat nut and tighten down.





SEE FIGURES 58 - 60

FIG 58

LOOK OVER YOUR WORK

STEP 27

SEE FIGURES 61 & 62

27) At this point, you should examine and carefully look over your work. Inspect for proper alignment depth and fitment.

GRILLE SHELL ASSEMBLY CONTINUED

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIFRRA 1500





STEP 28

28) Once satisfied with the grille insert installation, proceed with grille re-assembly.

STEP 29

29) Take the radiator induction shroud that was set aside earlier and align it over your new T-Rex Grille assembly. Line up the tabs and set it down in place.

SEE FIGURES 63 & 64



STEP 30

SEE FIGURE 65 - 66

SEE FIGURES 61 & 62

30) Use the plastic push tabs to secure and fasten down.

STEP 31

SEE FIGURE 67

31) Take the complete grille assembly, put into place and position to nose of vehicle.



GRILLE SHELL ASSEMBLY COMPLETE

FIG 65 FIG 66

OPTIONAL BADGE MOUNTING

STEP 32


32) For those that do want to feature the GMC Badge, you will need to first remove it from the factory grille. Flip it face down to access the tabs that secures the badging. From the back side, use a flat head screw driver to pry the tabs free and pop loose the badge. From the front side pull free from the factory grille. Snap off those tabs, position and mount badging to

PAGE 9

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500





STEP 33

33) Starting at the top, slip the grille assembly (shell) mounting tabs up and onto their mounts.

STEP 34

FIG 74

34) Note the "Male Post" and "Female Insert" will help locate the correct position of grille assembly.

SEE FIGURE 70





STEP 35 & 36

SEE FIGURES 71 - 74

35) Position lower mounts and finally re-install all factory hardware.

SEE FIGURES 75 & 76

SEE FIGURES 68 & 69

36) Re-Install lower bumper valance.





GRILLE SHELL ASSEMBLY COMPLETE

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

STEP 38

2016-2017 GMC SIERRA





STEP 37

SEE FIGURES 77 & 78

SEE FIGURES 79 - 85

37) Carefully slip valance into place underneath headlights. Give it a firm press to get everything into position. Fit Valance up and mate it to front fender and finally slip fender trim back over each piece so it all fits nice and tight.

38) Put Core Support Cover back into place and fasten Re-Install all hardware that was removed in step #4.









GRILLE SHELL ASSEMBLY COMPLETE

GRILLE INSTALL - START

LASER BILLET GRILLE MAIN GRILLE INSERT - #6202130 / #6202131

2016-2017 GMC SIERRA 1500



STEP 39

39) Check over your work for hardware tightness and visual inspection.

SEE FIGURES 86 - 88

40) At this point you want to look over your work and examine the gap alignments around all edges and in between the new T-REX Grille and the vehicle components and body lines. Carefully close the hood for a complete visual inspection. If adjustment is needed, you can remove grille and loosen the hardware mounts and shift side to side or up & down to achieve proper look.

GRILLE INSTALL - COMPLETE

