

Installation Instructions

T-Connector



Chevrolet Traverse

⚠ WARNING



ALWAYS read and follow all warnings and instructions included with purchase before beginning installation. Keep for future reference.

DO NOT exceed lower of towing manufacturing rating (including in your vehicle owner's manual) or specific amperage ratings stated on product.

ALWAYS read, understand and follow all warnings and instructions printed on tow vehicle's battery.

ALWAYS wear safety glasses and use all safety precautions during installation.



Fascia Removed For Clarity

TOOLS REQUIRED:

Trim Panel Remover, Test-probe

1. Locate the vehicle's towplug located under the vehicle on the driver side. Disconnect the mating protective cover and discard. Connect the towplug harness into mating harness. Check to see that the mating surfaces of the wiring connectors match. All Connector surfaces should be clean and free of dirt. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place. **A B**

2. Route the T-Connector harness rearward to the back of the fascia of the bumper.

⚠ WARNING

Route the wire being careful to avoid any hot pipes, heat shields, the fuel tank or any other points that may pinch or break the wire.

3. Secure 4-Flat tow harness to hitch. Bracket not included.

⚠ WARNING

Secure the remainder of the T-One® T-Connector harness under the bumper with cable ties provided, being careful to avoid any areas that would cut or pinch the wire.

⚠ WARNING

All connections must be complete for the T-One® T-Connector to function properly. Test and verify installation with a test light or trailer once installed. For initial test, reset vehicle electrical system by temporarily removing the key from the ignition.



⚠ WARNING

Overloading circuits can cause fires. **DO NOT** exceed stated product ratings. Read vehicle's owner's manual & instruction sheet for additional information.