

Installation Instructions

T-One® T-Connector



Acura RDX

⚠ WARNING



ALWAYS read and follow all warnings and instructions included with purchase before beginning installation. Keep for future reference.

DO NOT exceed lower of towing manufacturing rating (including in your vehicle owner's manual) or specific amperage ratings stated on product.

ALWAYS read, understand and follow all warnings and instructions printed on tow vehicle's battery.

ALWAYS wear safety glasses and use all safety precautions during installation.



ENGLISH

TOOLS REQUIRED:

Trim Panel Remover, 10mm Socket & Ratchet or 10mm Wrench, Drill (3/32" Drill Bit), 1/4" socket, Wire Crimpers, Wire Cutters, Philips Head Screwdriver, Test-probe

1. Open rear hatch. Temporarily remove the rear threshold plate, privacy screen, storage covers and floor covering. Open rear door and fold rear seat forward. Several trim panel fasteners will need to be removed to remove the panels. **A B C D**
2. Being careful not to damage clips, partially remove the lower interior trim panels on driver's side of the vehicle only. Several trim panel fasteners will need to be removed to remove the panels. Set aside all items removed being careful not to damage parts. **E**
3. Locate the vehicle's 8-pin connector located behind the rear interior trim panel. Insert the 8-Pin Tow-Plug Adapter and lock into place. **F**

4. Option 1:

On the driver's side, locate existing ground stud. Loosen bolt, place screw eyelet on stud and re-tighten bolt.

⚠ CAUTION

Make sure all other ground connections are secure when removing and reattaching the ground stud.

Option 2:

Locate a suitable grounding point near the connector such as the vehicle's frame or crossmember. (Do not drill into vehicle floor or bed.) Clean dirt and rustproofing from area. Drill a 3/32" hole and secure white wire using eyelet and screw provided.

⚠ CAUTION

Verify what is behind any surface prior to drilling to avoid damage to the vehicle and/or personal injury. Do not drill into any exposed surfaces.

⚠ WARNING

All connections must be complete for the T-One® T-Connector to function properly. Test and verify installation with a test light or trailer once installed. For initial test, reset vehicle electrical system by temporarily removing the key from the ignition.

5. Locate a flat surface in an out of the way place and mount the T-One® T-Connector's black box-module, to prevent damage or rattling.

6. Secure the remainder of the T-One® T-Connector harness with the cable ties provided, to prevent damage or rattling and being careful to avoid any areas that would pinch, cut or melt the wire.

NOTE

Store 4-Flat connector in rear cargo area when not in use. When in use pull 4-Flat through the door and close.

⚠ WARNING

Be careful not to pinch harness in door latch.

7. Reinstall the plastic trim panels, threshold, storage covers, floor covering and other items removed during installation, being careful not to pinch or cut the wires.



⚠ WARNING

Overloading circuits can cause fires. **DO NOT** exceed stated product ratings. Read vehicle's owner's manual & instruction sheet for additional information.