



# JK 3" Lift Kit Master Check List



## Important Notes:

Prior to beginning this or any installation read these instructions to familiarize yourself with the required steps and evaluate if you are experienced and capable to personally perform these modifications. A factory service manual should be used in conjunction with these installation instructions.

This product will change the handling characteristics of your vehicle, drive with caution. A full four-wheel alignment is required after the installation of this product. We recommend your local, ASE Certified mechanic.

Refer to the parts list to ensure that all necessary components and hardware has been included. If any parts are missing please contact your local TeraFlex dealer for assistance.



### 3" Short Arm Lift Box Contents at a Glance

Spring Box	
Springs	Front and Rear
Rear Brake Line Extension Brackets	1 Kit
Front Brake Lines	1 Kit
Quick Disconnect Links	1 Kit
Bumpstop Extensions	Front and Rear
Rear Track Bracket	1 Kit
Spring Spacers	Front and Rear

Flex Arms Box (Varies by kit)	
Front Uppers	2
Front Lower	2
Rear Uppers	2
Rear Lower	2

Track Bar Box (Varies by kit)	
Monster Front Track Bar	1

Shocks Box (Varies by kit)	
Shocks	2 Front; 2 Rear

Carefully check this list prior to beginning the installation. If any parts are missing please contact your local Teraflex dealer for assistance. See installation instructions for more detailed parts lists.



## **JK 3" Short Arm Lift Kit**

### **Master Installation Check-List**

- Remove the Rear Shocks (See 999207 JK Shocks)
- Remove the Rear Sway Bar Links (See 999184 JK Rear Swivel Sway Bar Links)
- Disconnect the Rear Track Bar at the frame
- Install the Rear Brake Line Extension Brackets (See 999219 Rear Brake Line Extension Brackets)
- Remove the Rear Springs (See 999206 JK Springs/Rear)
- Install New Rear Control Arms (See 999207 JK Short Arms/Rear Upper and Rear Lower per kit contents)
- Install the Rear Bumpstop Extensions (See 999156 JK Rear Bumpstop Extensions)
- Install the Rear Spring Spacers (999221 JK Spring Spacers/Rear)
- Install the New Rear Springs (See 999206 JK Springs/Rear)
- Install the Rear Track Bar Bracket (See 999152 for Frame Side or 999091 for Axle Side)
- Install the New Rear Sway Bar Links (See 999184 JK Rear Swivel Sway Bar Links)
- Install the Rear Shocks (See 999207 JK Shocks/Rear)
- Install the Track Bar Once the Vehicle is on the Ground (See 999152 for Frame Side or 999091 for Axle Side)
- Remove the Front Sway Bar Links
- Remove the Front Track Bar (See 999208 JK Front Track Bar)
- Remove the Front Shocks (See 999207 JK Shocks)
- Remove the Front Springs (See 999206 JK Springs)
- Install the New Front Control Arms (See 999207 JK Short Arms/Front Upper and Front Lower per kit contents)
- Install the Front Bumpstop Extensions (See 999209 JK Front Bumpstop Extensions)
- Install the Front Spring Spacers (See 999221 JK Spring Spacers/Front)
- Install the Front Springs (See 999206 JK Springs)
- Install the Front Shocks (See 999207 JK Shocks)
- Install the New or Reinstall the Factory Front Track Bar Once the Vehicle is on the Ground (See 999208 JK Front Track Bar)
- Install the Front Quick Disconnects (See 999027 JK Quick Disconnects)



### 3" Long Arm Kit Box Contents at a Glance

Spring Box		Long Arm Box (2 Boxes)		Monster Trackbar Kit	
Springs	2 Front; 2 Rear	Front Lower Arms	2	Trackbar	1
Brake Line Extensions	1 Kit	Front Upper Arms	2	Speedbumps (Kits 1257292 and 1257290)	
Front Quick Disconnect Links	1 Kit	Rear Lower Arms	2	Front Speedbumps	2
Bumpstop Extensions	Front and Rear	Rear Upper Arms	2	Rear Speedbumps	2
Rear Trackbar Bracket	1	Long Arm Bracket Box			
Rear Coil Spring Retainers	1 Kit	Rear Bracket	2		
Shock Box (Kits #1257200 and 1257202 Only)		Front Bracket	2		
Shocks	2 Front; 2 Rear	Gussets	2		

Carefully check this list prior to beginning the installation. If any parts are missing please contact your local Teraflex dealer for assistance. See installation instructions for more detailed parts lists.



## JK 3" Long Arm Lift Kit

### Master Installation Check-List

- Remove the Rear Shocks (See 999207 Shocks/Rear/Removal)
- Remove the Rear Sway Bar Links (See 999191 Rear Sway Bar Links/Removal)
- Disconnect the Rear Track Bar at the axle (See 999043 Rear Track Bar/Removal)
- Remove the Rear Springs (See 999206 Springs/Rear/Removal)
- Remove the Front Sway Bar Links (See 999027 Front Quick Disconnects/Removal)
- Remove the Front Shocks (See 999207 Shocks/Front/Removal)
- Remove the Front Track Bar (See 999208 Front Track Bar/Removal)
- Remove the Front Springs (See 999206 Springs/Front/Removal)
- Install the Long Arms and Brackets (See 999090 Long Arms and Brackets)
- Install Exhaust Spacers (2012+ Only) (See 999072 Exhaust Spacers)
- Install the Rear Extended Bumpstops and SpeedBumps (If included) (See 999017 and 999018 Speedbumps AND/OR 999209 and 999156 Extended Bumpstops)
- Install Rear Spring Spacers (See 999221 JK Spring Spacers/Install)
- Install Rear Springs (See 999206 Springs/Rear/Install)
- Install Rear Extended Sway Bar Links (999191 Rear Sway Bar Links/Install)
- Install Rear Shocks (See 999207 Shocks/Rear/Install)
- Install the Rear Track Bar Bracket (See 999091 Rear Track Bar Bracket)
- Reconnect the Rear Track Bar (See 999043 Rear Track Bar)
- Install Front Extended Bumpstops and SpeedBumps (If included) (See 999017 and 999018 Speedbumps AND/OR 999209 and 999156 Extended Bumpstops)
- Install Front Spring Spacers (See 999221 Spring Spacers/Front)
- Install Front Springs (See 999206 Springs/Front/Install)
- Install Front Shocks (See 999207 Shocks/Front/Install)
- Install New Front Track Bar Once the Vehicle is on the Ground (See 999208 Front Track Bar/Install)
- Install Front Quick Disconnect Links (See 999027 Front Quick Disconnects/Install)
- Install Front and Rear Extended Brake Lines or Brake Line Extension Brackets (See 999154 Extended Brake Lines)