

TERAFLEX

PRODUCT INSTALLATION GUIDE

Installation Guide for the JK Adjustable Front Track Bar Part #1753418



1. Remove the stock track bar using 21mm socket.(Photo #1)
2. Bounce the vehicle up and down several times to bring the axle centered under the vehicle. It may be helpful to use a ratchet strap to pull the axle to one side or the other to center the axle. Make sure it is centered correctly.
3. Install the frame end of the track bar to the frame bracket with the factory bolt. (Photo #2)
4. Adjust the track bar length so the axle end bracket lines up with the flex joint on the new adjustable track bar.
5. Install the frame end bolt and torque both bolts to 125 foot pounds with the Jeep on the ground. Torque the collar bolts to 80 ft-lbs. when axle is centered under jeep. (Photo #3)



This front track bar will fit all JK Wrangler models. Installation and final length adjustment should be done with the vehicle on the ground.