

TERAFLEX

INSTALLATION GUIDE

TJ Brake Light Extension Bracket

Boxed-Part #1902000

Skin Packed-Part #1902020



INSTRUCTIONS:

1. Remove the spare tire.
2. Release brake light wiring from retention clips to allow for extended length. Remove the bolts on the bottom of the brake light tower.
3. Place the brake light extension plate between rear tire mount and the brake light tower. The top of the extension plate should match the contour of the rear tire mount.
4. Attach the bottom of the brake light extension plate to the tire mount using the bolts removed in Step 2.
5. Connect the brake light tower to the top of the extension plate using the included hardware. Be sure to use a washer on both the top and bottom of the bolt, the larger washer being used on the top.
6. Reconnect the wiring loom into the one of the retainer clips if possible
7. Reinstall the spare tire.



NOTE: Use of spare tires over 33" diameter may block or reduce visibility of the third brake light.

Kit Contents:

| COMPONENT # | DESCRIPTION | QTY |
|-------------|-----------------------|-----|
| 600532 | brake light extension | 1 |
| 5017 | hardware bag | |
| | 5/16"x18x1 bolt | 4 |
| | 5/16" flat washer | 4 |
| | 5/16" fender washer | 4 |
| | 5/16" stover lock nut | 4 |