

FRTR350

PART NUMBER	DESCRIPTION	QTY	LOCATION
F11542-750	HCS M10 x 60 x 1.5 F/T Gr 8.8 Z	2	I2D
F11548-350	HCS M10 x 90 x 1.5 Gr 8.8 Z	2	I2C
A00540-55Q30	Hollow Rubber Spring	2	C9A
A25723-90AH00	RUBBER SPACER 4"od x 1" thk w/ AH Bushing	2	
K10086-003	DDR1004 / GMRJB WELDMENT PTD.	2	D11B
B90200-CR	SMALL REAR BOX - 9.5 x 7 x 5.5	1	A--E
B10000	8" x 12" BUBBLE FOR KITS	1	
B00029-010	BARCODE LABEL FOR KIT	1	

Clearance Instructions:

Rear SES Kits for Pick-Ups and Vans should have a 1/2" to 1-1/2" gap between the rubber spring and contact point when empty.

A partial load, or vehicle accessories will reduce or eliminate the gap.

Front SES kits are usually in full contact.

Medium and Heavy-Duty Trucks, Trailers and Motorhomes will be in constant contact, and have no gap.