

# ***TONNO PRO***

## **#LR-1045 / LR1050**

### **2014 Chevrolet / GMC Roll Up Cover**

**STEP 1:** Locate Plastic Plug in the rear inside of the stake pocket and remove.



**STEP 2:** Insert 1/2 of the rear clamp into the stake pocket. (clamp w/ 2 flat grips)



**STEP 3:** Position the longer clamp bracket w/ plastic insert and align to inner bracket. connect both using the provided bolt and washers.



**STEP 4:** Install the Aluminum Side Rail starting at the front using the smaller clamps provided. Slide the Side Rail into the rear clamp system. Continue Following Standard Installation Instruction Manual.



Learn more about tonneau covers we have.