

**Jeep CJ5 4WD; 1976-86 CJ7 4WD;
CJ8 Scrambler 4WD
1.5" Wheel Spacer 5 x 5.5 Bolt Pattern**

Parts:

2 - 1.5" 5-Lug Wheel Spacers 5 - Lug nuts

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any lifting devices. Any and all claims implied in this document excluded.

NOTES:

Check spacers regularly to ensure tightness.

REQUIRED TOOLS:

Floor Jack

Jack Stands

Torque Wrench

Socket Set

Socket Wrench

INSTALLATION INSTRUCTIONS

STEP 1: Chock tires to avoid vehicle roll. Jack up vehicle so that wheels are just off the ground.

STEP 2: Remove all lug nuts. (Socket wrench)

STEP 3: Remove wheels/tires.

STEP 4: Check for factory retaining washers and remove if present. Wheel spacer must sit flat against the rotor. Vibrations may occur if washers are not removed.

STEP 5: Install wheel spacers on studs. Secure with supplied lug nuts and tighten to factory specs. (Torque wrench) **DO NOT OVERTIGHTEN**

STEP 6: Re-install wheels/tires.

STEP 7: Re-install factory lug nuts and tighten to factory specs. (Torque wrench) **DO NOT OVERTIGHTEN** Be sure that wheel is flat against spacer and that lug nuts are tight against wheel.

POST-INSTALLATION

MAINTENANCE: Always check that wheel is flat against spacer and that lug nuts are tight against wheel. Wheel lug nuts should be re-tightened to factory torque specs. periodically. Always inspect components and re-tighten lug nuts during routine service.

[View other wheel spacers and adapters made by Top Gun Customz on our website.](#)