



TRUE FRAME MOUNTED CAMPER TIE DOWNS

IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS

A7201
1-1/4" SPACER KIT

PARTS INVENTORY

4- THREE HOLE TOP PLATE

4- U CHANNEL BOTTOM PLATE

U CHANNEL BOTTOM PLATE



THREE HOLE UPPER PLATE ON TOP OF U CHANNEL BOTTOM PLATE



PLACE BOTH BRACKETS ONTO THE STABLELOAD, WITH THE THREADED ROD PROTUDING THROUGH THE HOLE





REPEAT ON ALL FOUR STABLEADS-

PLEASE REFER TO INSTALLATION GUIDE FOR A7200

