



**OVER 35 YEARS OF INNOVATION, QUALITY, SAFETY.**  
**IMPORTANT OWNER-OPERATOR INSTALLATION INSTRUCTIONS**

**M9002/20K MAGNUM**

**PINTLE ADAPTER**

**3/4" HOLES**

**-M9000 20K MAGNUM SHANK**

**-M9001 20K MAGNUM SHANK XL**

Minor movement (or settling) can occur in some incidental harsh driving conditions (On or off road). A rubber bed mat is not a requirement to maintain the lifetime warranty on a Torklift system, but a strong recommendation, simply as a safety precaution to protect the truck bed, the bottom of the camper and to give the camper additional support.

**Warning!!**

**TORKLIFT DOES NOT RECOMMEND: Installing your truck camper in your truck on top of a drop in plastic bed liner!!! THIS WILL VOID YOUR WARRANTY!**

The drop in plastic bed liners can slide on top of the truck bed surface, and the camper can slide on top of the slick surface of the bed liner. The liner can also act as a spring causing a trampoline effect increasing vertical truck camper movement, independent of the vehicle, possibly resulting in truck bed damage and/or camper damage!

# **M9002 PARTS INVENTORY**

**1- 20K MAGNUM PINTLE ADAPTER**

**4- 1/2"X2-1/2" HEX BOLT GRD 8**

**4- 1/2" HEX NUT GRD 8**

**8- 1/2" SAE FLAT WASHERS**

**4- 1/2" LOCKWASHERS**

**2- 3/4"X4-1/2" GRD 8 BOLTS**

**2- 3/4" HEX NUT GRD 8**

**2- 3/4" LOCKWASHERS**

**1- 3/4"X1-1/2" GRD 8 BOLT.**

**NOTE- PARTS THAT ARE FADED SOLD SEPERATELY.**



**NOTE: ALL HARDWARE MUST BE TIGHTENED TO 100 FT POUNDS**

**-M9008/M9009 25K AND 30K BALLS SOLD SEPERATELY**

