




D25LL1 & D20LL1

2.5" & 2.0" Front Lift Leveling Kit



Fit: 2006 - Current

Dodge Ram 1500 4WD



REMOVE CONTENTS FROM BOX.
VERIFY ALL PARTS ARE PRESENT.




35" x 11.5"



READ INSTRUCTIONS CAREFULLY
BEFORE STARTING INSTALLATION.



60-120 min



May require rear block/spacer on certain applications

PARTS LIST:

Qty	Part Description	Qty	Part Description
6	Nuts 10mm X 1.25 mm		

Place vehicle on level ground, check the rear wheels lift and support properly with jack stands. Remove front wheels and tires.

1



2

Loosen and remove lower sway bar nut.



3

Disconnect lower strut mount.



4

Loosen upper ball joint nut. Leave attached.



5

Carefully strike spindle to break upper ball joint loose.



6

Picture shows separated upper ball joint. Note gap.



FINAL CHECKS & ADJUSTMENTS



Post Installation Check:

- Once the vehicle is lowered to the ground, check all parts which have rubber or urethane components to insure proper torque.
- Torque wheels to factory specs.
- Move vehicle backwards and forwards a short distance to allow suspension components to adjust.
- Turn the front wheels completely left then right and verify adequate tire, wheel, brake line, and ABS wire clearance.
- Test and inspect steering, brake and suspension components for tightness and proper operation.
- Inspect brakes hoses and ABS lines for adequate slack at full extension.
- Test drive vehicle and re-check the torque of all fasteners and re-torque wheels on vehicle.

NOTE: Failure to perform the post inspection checks may result in vehicle component damage and/or personal injury or death to driver and/or passengers.

Wheel Alignment/Headlamp Adjustment:

- ✓ It is necessary to have a proper and professional wheel alignment performed by a certified alignment technician.
- ✓ Align the vehicle to factory specifications.
- ✓ It is recommended that your vehicle alignment be checked after any off-road driving.
- ✓ In addition to your vehicle alignment, for your safety and others, it is necessary to check and adjust your vehicle headlamps for proper aim and alignment.

Vehicle Re-Torque and Safety Inspection:

Upon completion of all services and adjustments performed on your vehicle, and within 50 miles of driving, check to ensure all fasteners and hardware are properly torqued to specification as noted in the vehicles factory service manual.

Check out these other TrailFX Products!!



HOOP STEPS



HD GRILLE GUARDS



WINCHES



LED LIGHTS

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.