



Part # 1324

SPIN-ON OIL FILTER ADAPTER

1968-Up SB (and all BB) Chevrolet V8 with 3/4-16" nipple.

1. Remove and discard the stock oil filter unit.
2. Remove the pressure relief valve body from the oil filter cavity in the engine block, and discard it. Be sure to remove all old gasket material from the engine block.
3. Install the **TRANS-DAPT** oil filter adapter body in the oil filter cavity using the cap screws (*furnished*).
4. Screw the 3/4" threaded nipple (*furnished*) in to the adapter body. Screw in 3/8" deep.
5. Install the new gasket on to the adapter cover. Place cover (machined surface facing down) over the oil filter cavity, and secure it to the adapter body with the Pal nut (*furnished*). **DO NOT OVER TIGHTEN THIS NUT!**
6. It is recommended that a **TRANS-DAPT** #1156, or Fram PH-8 Spin-on Oil Filter be used with this adapter. **Be sure to follow the manufacturer's installation instructions carefully when installing any spin-on element to this adapter.**