

B-light **BATTERY POWERED** **TRUCK BED LIGHTING SYSTEM**

Installation Instructions:

1. Clean area where B-Light LED light strip is to be attached with rubbing alcohol or similar product before installing
2. Using a Phillips head screwdriver, open battery box and install **(3) AA** batteries (not included), Re-attach box cover with Phillips head screwdriver.
3. **IMPORTANT:** B-Light strip adheres best when temperature is between 60°F/15°C – 100°F/38°C.
4. Peel protective layer from 3M adhesive strip and attach to surface.
5. Firmly press battery box and LED light strip to secure in place.



On our website you can discover more about Tonneau Covers.