



# Installation Instruction

## Grille Guard

### 05-07 Nissan Pathfinder/ 05-12 Frontier

#### Part #



---

▪	1	Set	Grille Guard	▪	2	pc	5/16 x 1" Nut Plates
▪	1	Set	Frame Brackets(left & right, when sitting in the car)	▪	1	Set	Top Support Bracket
▪	6	pc	7/16X 1-1/4"Hex Bolts	▪	6	pc	7/16 Nylon Lock Nuts
▪	12	pc	7/16 Flat Washers	▪	4	pc	1/2 Washers
▪	4	pc	M12-1.25 x 40mm Bolts	▪	6	pc	5/16 Flat Washers
▪	4	pc	5/16 x 1" Hex Bolts				

---

#### **Instructions:**

1. REMOVE LOWER AIR DAM FROM FRONT BUMPER (REMOVE TEMPORARY)
2. REMOVE TIE DOWN FROM BOTTOM OF PASSENGER SIDE FRAME RAIL. DISCARD TIE DOWN. USING THE BOLTS FROM THE TIE DOWN. ATTACH PASSENGER SIDE FRAME BRACKET TO BOTTOM OF THE FRAME.BOLT UP FINGER TIGHT.
3. ATTACH DRIVER SIDE FRAME BRACKET (DRIVER SIDE SHOWN) USING THE 12MM-1.25X40MM HEX BOLTS AND 1/2 WASHERS.BOLT UP FINGER TIGHT.
4. USE A UTILITY KNIFE AND CAREFULLY CUT SLOT IN THE BOTTOM PLASTIC AIR DAM TO FIT AROUND THE FRAME BRACKETS. REATTACH LOWER AIR DAM.
5. LINE UP THE THREE HOLES ON THE LOWER PORTION OF THE BAR WITH THE THREE OF THE HOLES IN THE FRAME BRACKETS(**OUTER EDGE**).ATTACH FRONT BAR USING THE 7/16X1-14 HEX BOLTS. 7/16 NYLONG LOCK NUTS AND 7/16 FLAT WASHERS. SNUG TIGHT ONLY.

#### **INSTALLING TOP SUPPORT BRACKETS**

1. ATTACH TOP SUPPORT BRACKETS UNDERNEATH CENTER PLATE OF THE FRONT BAR (SHORTER END AS SHOWN) USING THE 1/4X3/4 SCREWS.
2. SLIDE THE 5/16 NUT PLATE TROUGH THE INSIDE OF BUMPER AS SHOWN TO ATTACH THE LONGER END OF THE TOP SUPPORT BRACKETS SECURE USING THE 5/16X1" HEX BOLTS AND 5/16 FLAT WASHERS.
3. ALIGN FRONT BAR ASSEMBLY WITH FROM OF THE VEHICLE AND SECURE ALL FASTERNs.

