

Driver/Left Side Installation Pictured	Installation Instructions Part#:1-0581			
Driver/Left Olde Installation Fictured	Side Bar for Nissan Pathfinder 99	.5-04		
		2	r	
8 Front			2	4
	<u>5</u> N0	NAME	QTY	_
	<u> </u>	HEX BOLT	12_	M8*25
	NO	HEX BOLT FLAT WASHER	12 12	_
	N0 1	HEX BOLT FLAT WASHER HEX BOLT	12 12 8	M8*25 Φ8 M12*40
	N0 1 2	HEX BOLT FLAT WASHER	12 12	М8*25 Ф8
	N0 1 2 3	HEX BOLT FLAT WASHER HEX BOLT FLAT WASHER HEX NUT	12 12 8	M8*25 Φ8 M12*40
	N0 1 2 3 4	HEX BOLT FLAT WASHER HEX BOLT FLAT WASHER	12 12 8 16	M8*25 Φ8 M12*40 Φ12
	N0 1 2 3 4 5	HEX BOLT FLAT WASHER HEX BOLT FLAT WASHER HEX NUT	12 12 8 16 8	M8*25 Φ8 M12*40 Φ12
	N0 1 2 3 4 5 6	HEX BOLTFLAT WASHERHEX BOLTFLAT WASHERHEX NUTREAR MOUNTING BRACKET	12 12 8 16 8 2	M8*25 Φ8 M12*40 Φ12