



4653 POWER BRAKE BOOSTER BRACKETS

CAREFULLY READ THESE INSTRUCTIONS BEFORE ATTEMPTING ANY MODIFICATIONS!

Proper installation of this power brake booster bracket is the responsibility of the installer. Improper modification or installation will void your warranty and may result in vehicle damage or personal injury.

INSTALLATION INSTRUCTIONS

Remove original power brake booster and bracketry.
Mount new bracket assembly as shown above.
Remount power brake booster.



POWER BRAKE BOOSTER BRACKET ASSEMBLY FOR GM TRUCKS 1960 - 1972

Works with 2 hole OEM bracket setups late 1960 through 1972. Includes pedal rod and clevis

Fits 1960 - 72 GM truck booster combos 2122, 2123, 2124 & 2128

Fits 1960 - 72 GM truck power brake boosters 2222, 2223, 2224 & 2228

Chrome plated finish 4653A, Stealth black powder coated finish 4653B