



INSTALLATION INSTRUCTIONS

Mounting Kit #076 for Ford Bronco '66-'77

PARTS CHECKLIST

- (3) 1" Spacers
 - (3) 5/16 x 1 3/4" Bolts
-
1. Follow the installation instructions for the console but replace the portion of the instructions about fastening the console to the vehicle with these steps.
 2. For this mounting application the mounting bracket included with the console and some of the mounting hardware will not be used.
 3. Fasten down the console with (3) 5/16 x 1 3/4" bolts (included with this shipping package), (3) 5/16 nylock nuts (included in the consoles shipping package), and (6) 5/16" washers (included in the consoles shipping package) using (2) 1" spacers in the rear of the console and (1) 1" spacer in the front of the console (if required).