

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800014P2

Estimated Time : 10 min.

Replacement for OEM
999M1-VR056

05-10 Nissan Frontier
05-10 Nissan Pathfinder
05-10 Nissan Xterra



1. The filters are located behind the glove compartment. Open glove compartment and push on the sides while pulling down to disengage the latches.



3. Slide out old filters and install new TYC filters. Ensure that Air Flow arrow is pointing down for both filters.

4. Reinstall in reverse order.



2. Remove the filter access door by lifting up the locking tab. Set door aside.

Installation guide pictures are from the **BOLD** vehicle model.

Discover other A/C and heating parts on our website.