

# TYC™

## CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

**TYC #: 800018P**

Estimated Time : 10 min.

Replacement for OEM  
97619-338100

01-06 Hyundai Santa Fe (OP)  
**99-03 Hyundai Sonata (To 3-28-03)**  
01-05 Hyundai XG300/XG350



1. The filter is located behind the glove compartment. Remove the latches on each side of the glove box by pushing them inwards. Allow glove box to swing down on its hinges.



2. Remove the bolts and screws holding the back panel of the glove box in place. Pull down the entire panel to expose the filter access door behind it.



3. Remove the vertical filter access door by unlatching the bottom of the door and pulling it out. Slide out exposed filter and replace with new TYC filter. Ensure that Air Flow arrow is pointing to the driver's side.

4. Reinstall in reverse order.

\*OP = Cabin Air Filter is an OPTION on this application. Some vehicles may not come equipped with a Cabin Air Filter.

Installation guide pictures are from the **BOLD** vehicle model.

Discover other A/C and heating parts on our website.