

# TYC™

## CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

**TYC #: 800019P**

Estimated Time : 5 min.

Replacement for OEM  
15807286 (w/ Frame)  
25669930  
52472209

06-10 Buick Lucerne  
01-03 Oldsmobile Aurora  
**03-05 Pontiac Bonneville**



1. The filter is located under the hood, below the windshield at the passenger side. Open the filter cover by pushing on the 2 retaining tabs and then pulling the cover up.



3. Insert new TYC filter and frame back into vehicle at a 45 degree angle.

4. Reinstall in reverse order.



2. Remove the filter frame by reaching in and pulling it 45 deg upwards.  
If your vehicle does not have any filter frame, skip this step and proceed to step 3.\*

\*Note: Some vehicles may not come with the filter and filter frame pre-installed. If you do not have the filter pre-installed, proceed to install the new filter on your vehicle.

Installation guide pictures are from the **BOLD** vehicle model.