

- Cleaner Air for Passengers
- Enhanced HVAC Performance
- Easy Installation, Perfect Fit

TYC #: 800021P

Estimated Time: 10 min.

Replacement for OEM G3210FE100 (New) 72880FE000 (Old)



1. The filter is located behind the glove compartment. Remove 1 clip on the side and 2 screws beneath the compartment.



02-07 Subaru Impreza / Outback Sport

3. Remove filter access door by lifting on the 2 locking tabs.



2. Remove 7 screws to remove glove compartment.



- 4. Slide out old filter and install new TYC filter.
 Ensure that Air Flow arrow is pointing down.
- 5. Reinstall in reverse order.