

- Cleaner Air for Passengers
- Enhanced HVAC Performance
- Easy Installation, Perfect Fit

TYC #: 800027P

Estimated Time: 10 min.

Replacement for OEM 96539649 (New) 96435888 (Old)





1. The filter is located behind the glove compartment. Open glove box and push on the sides while pulling down to disengage the latches. Allow glove box to swing down on its hinges.



- 3. Remove the filter access door by releasing the locking clip. Set door aside. Remove old filter by sliding it out, and replace with new TYC filter.*
- 4. Reinstall in reverse order



2. Remove the 4 screws securing the metal support bar, and remove the entire bar.



*NOTE: Please note the installation direction on the frame when installing the filter. The arrow should be pointing upwards.