

Replacement for OEM 64 31 6 935 822 (Particle)

64 31 6 935 823 (Combination)

- Cleaner Air for Passengers
- **Enhanced HVAC Performance**
- Easy Installation, Perfect Fit

TYC #: 800028C2

04-08 BMW 5 Series

04-07 BMW 6 Series

06-07 BMW 5 Series Wagon



1. The filters are located in the engine bay, with one on each side, below the windshield.



3. Slide filter holder forward to remove. Remove old filter from its holder and install new TYC filter. Ensure that Air Flow arrow is pointing down.*

Estimated Time: 5 min.

4. Reinstall in reverse order and repeat for the other side.



2. Remove filter holder by unclipping the metal bar and loosening the plastic clip.



*NOTE: When installing the new filter, be sure to match up the notch on the filter and the filter housing.

Installation guide pictures are from the **BOLD** vehicle model.