

# TYC™

## CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

**TYC #: 800039P**

Estimated Time : 10 min.

Replacement for OEM  
52493319

05-10 Chevrolet Cobalt  
06-10 Chevrolet HHR  
07-10 Pontiac G5  
**03-07 Saturn Ion Coupe/Sedan**



1. The filter is located behind the glove compartment. Push in on the sides while pulling down to disengage the latches. Allow glove box to swing down on its hinges. This exposes the filter access door behind it.



2. Open the filter access door by lifting up the retaining tab.



3. Slide out the old filter, replace with new TYC filter, ensuring that the Air Flow arrow is pointing down.

4. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.

Discover other A/C and heating parts on our website.