

# TYC™

## CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

**TYC #: 800040P2**

Estimated Time : 5 min.

Replacement for OEM  
97617-1C000

02-06 Hyundai Accent (from 11-25-01)



1. The filters are located behind the glove compartment. Open glove box and push in on the sides while pulling down to disengage the latches. Allow glove box to swing down on its hinges.



3. Remove old filters (2 of them) by sliding them out towards you. Replace with new TYC filters, ensuring that Air Flow arrow is pointing to the driver's side.



2. Unhook the cable to gain access to the filter access door. Pinch on the 2 retaining tabs to release and pull out the filter access door. Set door aside.

4. Reinstall in reverse order.