

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800044P2

Estimated Time : 10 min.

Replacement for OEM
999M1-VP055

04-08 Infiniti QX-56
04-07 Nissan Pathfinder Armada
04-08 Nissan Titan



1. The filters are located behind the glove compartment. Remove the screws at the top of the glove compartment.



2. Identify and remove the remaining 2 screws at the bottom of the glove compartment. Remove compartment by pulling it outwards. This exposes the filter access door behind it.



3. Remove the single bolt that secures the filter access door. Remove door and set it aside. Slide out old filters, replace with new TYC filters. Ensure that the Air Flow arrow is pointing down for both filters.

4. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.

Discover other A/C and heating parts on our website.