

Cleaner Air for Passengers

Enhanced HVAC Performance

Easy Installation, Perfect Fit

TYC #: 800047P2

Replacement for OEM 80291-S84-A01

99-03 Acura 3.2 TL

01-03 Acura 3.2 CL

98-02 Honda Accord Coupe/Sedan



1. The filters are located behind the glove compartment. Remove the 4 screws that secure the glove compartment.



3. Remove the metal support beam by removing the 3 screws that secure it.

Estimated Time: 25 min.



2. Remove the panel beneath the glove compartment by removing the screw in the fuse box.



- 4. Push on the locking tab on the filter access door, remove door and set aside. Pull out old filters and install new TYC filters (2 pieces). Ensure that Air Flow arrow is pointing to the driver's side for both filters.
- 5. Reinstall in reverse

Installation guide pictures are from the **BOLD** vehicle model.