

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800059C

Estimated Time : 10 min.

Replacement for OEM
4596501AB (New)
4806294AA (Old)

05-10 Chrysler 300
06-10 Dodge Charger
05-10 Dodge Magnum



1. The filter is located under the hood, under the windshield on the passenger side. Push on the 2 tabs to remove the plastic cover.



3. Remove old filter by sliding it up. Insert new TYC filter, ensuring that the “Rear of car” arrow is pointing towards the back of the car.

4. Reinstall in reverse order.



2. Flip down on the filter access door to expose the filter sitting inside. *

*Note: The filter housing is optional on some vehicles. If you do not see the filter housing shown in the picture, purchase of a filter housing from your local dealer is required in order to have cabin air filtration capability.

Installation guide pictures are from the **BOLD** vehicle model.

Learn more about replacement A/C and heating parts on our website.