

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800060C

Estimated Time : 5 min.

Replacement for OEM
25906375 (New)
25689297 (Old)
25644414 (Old)

00-03 Buick LeSabre
00-05 Cadillac Deville
06-10 Cadillac DTS
01-02 Oldsmobile Aurora
00-02 Pontiac Bonneville



1. The filter is located under the hood, below the windshield on the passenger side. Open the filter cover by pushing on the 2 retaining tabs and then pulling the cover up.



2. Remove the filter frame by reaching in and pulling it 45 degree upwards.
(If your vehicle does not have any filter frame, please purchase TYC item:800019P to install)



3. Remove old filter from its frame. Install new TYC filter, ensuring that the Air Flow arrow is pointing down.

4. Slide back down frame & filter at a 45 degree angle. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.