

# TYC™

## CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

**TYC #: 800065P**

Estimated Time : 5 min.

Replacement for OEM  
XF2Z 19N619 AB

**04-07 Ford Freestar**  
99-03 Ford Windstar  
04-07 Mercury Monterey



1. The filter is located under the hood, near the passenger side. Locate the filter access door and push on the locking tab to remove it. Set door aside.



3. Replace with new TYC filter, ensuring that the Air Flow arrow is pointing down.

4. Reinstall in reverse order.



2. Push up slightly on the filter from its tray and slide it out to remove.

Installation guide pictures are from the **BOLD** vehicle model.

Feel the difference with TYC.

Discover other A/C and heating parts on our website.