



- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800098P

Replacement for OEM
95860-85Z00

Estimated Time : 10 min.

04-10 Suzuki Forenza
05-08 Suzuki Reno



1. The filter is located below the glove compartment. Look below the glove box towards the center of the vehicle.



3. Grab onto filter handle as shown and pull the old filter down to remove.



2. Locate and remove the 4 bolts securing the filter access door. Remove door and set it aside.



4. Bend the filter towards the right to have more clearance to continue to pull it down. Replace with new TYC filter by sliding it back up. Ensure that air flow arrow is pointing to the right.

5. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.

Feel the difference with TYC.

Discover other A/C and heating parts on our website.