

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800111P

Estimated Time : 5 min.

Replacement for OEM
EG21-61-P11
7T4Z 19N619 B

07-10 Mazda CX-9

07-10 Ford Edge
07-10 LN MKX



1. The filter is located behind the glove compartment. Open glove box and locate the filter access panel.



2. Release the filter access panel by depressing the clips and pulling the panel down. Remove panel and set it aside.



3. Remove the filter access door by releasing the clip on the left side. Remove door and set aside.



4. Slide out the old filter to remove; replace with new TYC filter. Ensure that the flat side is on the bottom.

5. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.

Looking for replacement A/C and heating parts? Visit our website.