

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800124P

Estimated Time : 10 min.

Replacement for OEM
64 31 9 127 515

07-10 Mini Cooper/ Cooper S



1. The filter is located below the glove box by the passenger side footwell. Pry open tabs at the front of filter cover to open. Allow filter cover to swing down on its hinges.



2. The filter will become visible after the filter cover swings down. Reach in using one hand and grab end of filter. Pull filter downward to remove.



3. Slide the entire filter out from its housing to completely remove.

4. Install new TYC filter by inserting it into the grooves of the housing and slide filter up. Ensure that the "Down" arrow on side of the TYC filter is pointing downward. Installed filter is curved like an "S" inside the housing.

5. Reinstall in reverse order.

Installation guide pictures are from the **BOLD** vehicle model.

Looking for replacement A/C and heating parts? Visit our website.