

- Cleaner Air for Passengers
- Enhanced HVAC Performance
- Easy Installation, Perfect Fit

TYC #: 800139P

Replacement for OEM ZZCA-61-J6X(Mazda) 8L8Z-19N619-B(Ford & Mercury)



1. The filter is located under the hood, below the windshield on the passenger side. Remove the 4 plastic screws to loosen the cover.



2. Lift up plastic cover to expose the filter cover. Flip open filter cover to gain access to the filter under it



08-10 Mazda Tribute 08-10 Mercury Mariner



3. Remove old filter from the tray by first lifting it up, then pulling outwards.

Estimated Time: 10 min.



- 4. Install new TYC filter. Ensure that the filter is seated snugly on the tray.
- 5. Reinstall in reverse order.

Installation guide pictures are from the **<u>BOLD</u>** vehicle model.

Looking for replacement A/C and heating parts? Visit our website.