

TYC™

CABIN AIR FILTER

- ▶ Cleaner Air for Passengers
- ▶ Enhanced HVAC Performance
- ▶ Easy Installation, Perfect Fit

TYC #: 800175P2

Estimated Time : 5 min.

Replacement for OEM
68071668AA

08-12 Jeep Liberty



1. The filters are located behind the glove compartment. Remove the glove box by pulling the glove compartment downwards.



3. Slide out the old filters and install new TYC filters. (TYC filters come in a set of 2) Ensure that the Air Flow arrow is pointing down for both filters.

4. Reinstall in reverse order.



2. After the glove box is removed, the filter access door is visible. Pull on the locking tab on both sides remove the door, exposing the filters inside.

Note: This application contains 2 identical filters.